itazte vv

user manual



The iTaste VV is a microprocessor controlled variable-voltage/ variable-wattage (VV/VW) personal vaporizer that lets you adjust the voltage or wattage in seconds with just a few button presses. It's quick and

Specifications:

Size: 15 1*15 1*99mm

Operating Voltage: 3.3V - 5.0V Operating Wattage: 6.0W - 11.0W Maximum Current Output: 3.5 ampere

Materials: Copper tube /aluminium tube + zinc alloy

Main Features:

Variable Voltage:

voltage can be adjusted from 3.3 - 5.0 volts in .1 volt

Variable Wattage

Wattage can be adjusted from 6.0 – 11.0 W in .5 watts

Ohms meter:

Resistive Load Detection.

Puff Counter:

The puff counter will record how many puffs you have taken. The records will be cleared when the device is turned off.

Short Circuit/Atomizer Protection:

Short Circuit/Atomizer Protection helps protect the iTaste VV against faulty atomizers.

Over-Discharge Protection:

The iTaste VV monitors the battery voltage and will automatically turn off when the battery is discharged.

LED Battery Indicator:

The iTaste VV battery utilizes an advanced capacity display via green, yellow and red LED lights. Users will know the battery's capacity via the color of the LED

The LED lights will show green, yellow or red to indicate full battery life, half capacity or charging

Superior Battery Life:

The iTaste VV e-cigarette features a built-in 800 mAh polymer Li-Ion rechargeable battery.

The iTaste VV is threaded to accept 510 accessories. including the iClear10, iClear16 and iClear30

ON/OFF Battery Switch:

Quickly clicking three times will power the device on or off. Once the device is on, holding down the button will activate the battery. This safety feature prevents the atomizer from turning on while it's in your pocket or bag, as well as inadvertent settings changes.

10-Second Cutoff:

If the button is held down for 10 seconds or longer, the iTaste VV will shut itself off until the button is released.

The iTaste VV is charged through a Micro USB Port You can recharge it with any standard MicroUSB

cable. It can also work as a pass-through device for simultaneous vaping and charging.

Settings Retention

The device remembers the last voltage or wattage used when switching batteries.

Display Information

The bright display shows resistance (ohms), voltage wattage, atomizer voltage output, puff count, and



Please keep out of reach from children and pets



Do not immerse battery in liquid, fire, or extreme heat.

WARNING:

Please read this section carefully to ensure you receive maximum benefits from your iTaste VV3.0 and enjoy vaping with it in the most safe and effective ways possible.

1. This Advanced Personal Vaporizer may be used with e-liquids that contain nicotine. Please check with your e-liquid provider. This product is only intended for use by adults of legal smoking age (18+) and should not be used by children, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure,

diabetes or taking medicine for depression or asthma, or who otherwise may be sensitive to nicotine. Nicotine is addictive and habit forming, and it is very toxic by inhalation, in contact with the skin or eyes, or if swallowed. Ingestion of the non-vaporized concentrated e-liquid ingredients can be poisonous. Keep away from children and pets.

- 2. This Advanced Personal Vaporizer may be used with e-liquids that contain nicotine, a chemical known to the State of California to cause birth defects or other reproductive harm. Please check with your e-liquid provider. (For products sold in
- 3. This Advanced Personal Vaporizer is only designed to be used with high quality e-liquid. Please check with your e-liquid provider. This device is not intended for use with loose tohacco leaf or herbal substances.
- 4. This Advanced Personal Vaporizer has not been evaluated by the Food and Drug Administration and is not intended to treat, mitigate, prevent or cure any disease or condition. This product is not intended for use as a smoking cessation device.
- 5. This product is intended for use with the charger provided with the unit. We recommend you always use a high quality 5V 500mA USB wall charger (CE/UL Certified). Use of unauthorized chargers may lead to overheating and possible burning of items in contact with the unit. Innokin Technology is not responsible for battery and charger explosions, fires or malfunctions due to the use of a low-quality charger. This product (iTaste VV Express kit)does not come included with any wall charger

6 This Advanced Personal Vanorizer does not come included with car charger or car charger adapter. This device is not designed for use with a car charger. Use of unauthorized chargers may lead to overheating and possible burning of items in contact with the unit.

7. All empty clearomizers must be disposed of

- properly and out the reach of children and pets. 8. This Advanced Personal Vaporizer includes small parts such as the mouth piece. Always keep any small parts out of reach of children and pets to prevent swallowing or other harm.
- 9. Obey local laws or regulations regarding Electronic Cigarettes when vaping. If you are in an area where there are any bans or potential dangers, please do not use your Advanced Personal Vaporizer.
- 10. Do not misuse, mishandle or store your Advanced Personal Vaporizer improperly. Even though it is made of high quality stainless steel itmay become damaged when dropped or otherwise mishandled.
- 11. Do not drop, throw, or mishandle your Advanced Personal Vaporizer as the outer shell or inner components may become damaged. If the shell of the device becomes damaged or the structural integrity of the battery becomes compromised, discontinue use immediately and contact your Authorized Innokin Technology
- 12. In order to prolong the operation of your Advanced Personal Vaporizer, please do not

place or store in excessively hot or cold environments.

- 13. Your Advanced Personal Vaporizer is not waterproof. Keep it dry at all times. Do not submerge this device or expose it to moisture.
- 14. Keep your Advanced Personal Vaporizer away from sources of excessive heat or cold as damage may occur.
- 15. Do not attempt to repair the unit by yourself as damage or personal injury may occur.
- 16. In order to guarantee the normal functioning of your Advanced Personal Vaporizer, and maximize the pleasure of vaping, we strongly advise that you charge the battery when the power level drops below 10 percent.
- 17. Do not leave the battery depleted for long periods of time between recharging or the battery capacity may be decreased.
- 18. Do not leave this device unattended while charging. 19. If the device becomes excessively hot,
- discontinue use immediately and contact your Authorized Innokin Technology Vendor. 20. If the device will not power off, discontinue use
- immediately and contact your Authorized Innokin Technology Vendor. 21. If the device functions in a way which is not
- stated in the manual contact your Authorized Innokin Technology Vendor.
- 22. As this device has an internal Lithium Ion Battery, the lifespan of the product will be

Please consult with Innokin official distributors for warranty and return policy. Innokin's warranty does not apply to products purchased through third-party

OPERATION GUIDE



There are three main buttons on the iTaste VV: "()" button, "+" button and "-" button; all the functions can be activated by using those three buttons to change settings in one step, your chosen mode will be

- "+" hutton: Increase voltage or wattage
- "-" button: Decrease voltage or wattage

Quickly clicking " " button three times will turn the hattery on or off. Once enabled, holding down the button will activate the battery.

Variable Voltage Mode:

Hold the "-" button first and then holding " ひ " button for two seconds to enter variable voltage mode. The digital screen will show the puff count first, then the last setting used (in voltage or wattage). Voltage can be adjusted from 3.3 to 5.0 volts in 0.1 volt increments by pressing the "+" and "-" button.

Variable Wattage Mode:

Hold the "+" button first and then holding "()" button for two seconds to enter variable wattage mode. The digital screen will show the puff count first , then the last setting used (in voltage or wattage). Wattage can be adjusted from 6.0W to 11.0W in 0.5 watts increments by pressing the "+" and "-" button.

Ohms Meter & Battery Level Indicator & Puff Counter:

Hold both the "+" and "-" buttons simultaneously for 2 seconds. The screen will show a series of readings, the first being the resistance of the attached load, the second being the battery voltage, the third being the number of puffs since the device was last turned off and the fourth being the last set voltage or wattage. If not load is attached the display with show "NON".

If you wish to check the number of puffs taken since the iTaste VV was last turned off, you can also hold either the "+" or the "-" button to display the Puff Counter which will be followed by the display of current mode (VV mode or VW mode). In this state, you can also adjust the voltage or wattage by pressing the "+" or "-" button.

LED Light Blinking Mode:

The LED light will blink in different colors to indicate the current battery voltage.

- 1. Red LED light = battery voltage lower than 3.6V 2. Yellow LED light = battery voltage between 3.6V and
- 3. Green LED light = battery voltage more than 3.7 V 4. Red LED will keep blinking for eight seconds when battery capacity is lower than 3.3V, after which the
- device will turn off automatically. 5. Red LED light will stay for five seconds when a load short circuit is detected or the current output of the coil is more than 3.5A, then no vapor will be produced.
- 6. If you take a long drag for more than 10 seconds, the battery will stop its output. The RED light will hlink 10 times and the device will not work until it's

Replace or refill the cartridge if vapor volume decreases The manufacturer is not responsible for damaged

atomizers, cartomizers or clearomizers. Driving the device with too much power for too long or may hurn out accessories

We recommend that you start with a low voltage setting and work your way up until when you find the right setting for your tastes.

Never use your iTaste VV without an atomizer, cartomizer or clearomizer. Connecting to a volt meter without the load required for high voltages can damage the device.

Although it's made of metal, the iTaste VV can be damaged by dropping. Use appropriate care. Set lower voltage /wattage for low-resistance (ohms) equipments and higher voltage/wattage for higher-resistance equipments.

CHARGING the iTaste VV



The color of the LED light indicates the remaining battery life.



Recharge iTaste VV with a standard Micro USB cable. It can also work as a passthrough for immediate use while charging.





Plug the USB cable into iTaste VV 's charging port and a power source.



iTaste VV 's button color indicates the charge level, after fully charged, the LED cut-off.









尺寸: 55*90mm, 6折页 颜色: 四色印刷

材质: 128g双铜板纸正反两面印刷

比例 Scale		100%	单位 Unit	mm	符合RoHS标准		INNOK		新宜康科技有限公司 INNOKIN TECHNOLOGY CO.,LTD		
修改记录	NO.	修改日期 Modify date			修改内容 Modify Content	型号 Model	itaste vv		料号 Part NO.		页次 Page
		2014.8.29	更改警告	 持语		名称 Name	英文说明书	}	客户 Customer		1 of 1
						制作 Made	赖伟健	确认 Confirmed		核准 Approved	
						日期 Date	2014.8.29				